

# ***Spy On A Bird™***

## ***Birdhouse with Wireless Camera and AC Adapter***



[www.SpyOnABird.com](http://www.SpyOnABird.com)

# Birdhouse with Wireless Camera instructions

## What's in the Box

Birdhouse in your choice of material and color

2.4 GHz wireless camera premounted in the birdhouse

Indoors power adaptor for receiver

A/V cables



Receiver for camera



100 ft AC Power Adapter



## **Setting up your Birdhouse**

1. Mount birdhouse in a desirable location. Remember to keep the birdhouse less than 100 feet from the receiver or the signal may be diminished.
2. Plug outdoor power adaptor into camera
3. Plug A/V cable from the receiver to the A/V input of the TV or VCR. Select the proper input channel of your TV or VCR. (Refer to manual)
4. Plug indoor power adaptor into receiver.

## ***Helpful Hints***

Always test the nestbox indoors before mounting outside.

Camera may have shifted during shipping. To re-adjust the camera position, open the lid (single screw) and manually tilt the camera until the picture is centered. The camera is pre-focused to an approximate depth of 6 inches above the floor.

The camera channel is marked on the lower left of the left side of the nestbox and on the back of the camera. The receiver channel is preset to the camera.

During low light conditions, the IR LED's will automatically turn on, resulting in a black & white display.

## ***Technical considerations:***

The camera is weather resistant, but if direct rain soaking occurs, some condensation will collect on the inside glass. Also, if the camera has not been used for some time, you may notice "fogging" of the lens. This usually clears after a few minutes of use.

The microphone is very sensitive. You may have to turn the volume down on your TV to hear properly.

Certain electronics may interfere with the camera reception; such as cordless telephones and wireless internet routers.

Microwave ovens may interfere with the signal while in use.

Sometimes, small adjustments in the location of the camera or the receiver can improve the reception.

Your neighbors' microwave oven, cordless telephone and wireless router may also interfere with your camera reception.

Temporary interference will occur if the wireless signal is obstructed, such as by moving the receiver or walking through the signal path.

## Optional Accessories

12 ft power extension cable



25 ft A/V cable



Video Adaptor



Long range antenna



100 ft AC power adapter



For more information on these accessories and other products, please visit our website. [www.SpyOnABird.com](http://www.SpyOnABird.com)

## **Warranty**

Every unit is tested and is guaranteed to work right from the box. Within the first 7 days, if you are not satisfied for any reason, please call us at 1-800-606-6428 and we will assist you in returning the items and issue a refund for the purchase price. Customer pays return shipping.

Every item also comes with a 6-month warranty from the purchase date. Please retain your original invoice. Damage related to normal wear and tear is excluded from this guarantee. Sorry – squirrel damage is not covered under our policy.

## **Disclaimer**

*Please obey all local laws and ordinance when operating these products. These products are prohibited from illegal activities. Our company shall not be responsible for any consequences of illegal conduct by the user*